

# BroadWeigh Product Overview



**BW-S475**  
BroadWeigh Wireless 4 3/4 ton Crosby Safety Bow Shackle



**BW-S325**  
BroadWeigh Wireless 3 1/4 ton Crosby Safety Bow Shackle



**BW-HR**  
BroadWeigh Wireless Handheld Display



**BW-BSue**  
Extended Range USB Base Station



**BW-AR**  
Active Repeater for T24 Wireless Telemetry



**BW-WSS**  
Wireless Wind Speed Sensor



**BW-CASE-A**  
BroadWeigh Case (up to 12 shackles)



**BW-CASE-B**  
BroadWeigh Case (up to 8 shackles)




**BW-INSERT(A)**



**BW-INSERT(B)**



**BW-INSERT(C)**



**Software**  
**BW-LOG100**

# BroadWeigh Configuration



Up to 100 BroadWeigh Shackles



800 m Wireless Range



**BroadWeigh Wireless USB Base Station**  
Displays data from load shackles and allows configuration of all parts of the system

And / Or



**BroadWeigh Wireless Handheld Display**  
Displays data from load shackles and allows the user to "sleep" and "wake" the system

Up to 100 BroadWeigh Shackles